

ENJOY USB-C adapteri Garmin kelloille



Yhteensopivat kellot:

Approach G12, Approach S10, Approach S12, Approach S40, Approach S42, Approach S60, Approach S62
Approach X10, D2 Air, D2 Air X10, D2 Charlie, D2 Delta, D2 Delta PX, D2 Delta S, D2 Mach 1, Enduro,
epix (Gen 2), fēnix 5, fēnix 5 Plus, fēnix 5S, fēnix 5S Plus, fēnix 5X, fēnix 5X Plus, fēnix 6 / Solar
fēnix 6 Pro / Solar, fēnix 6S, fēnix 6S Pro / Solar, fēnix 6X Pro / Solar, fēnix 7, fēnix 7 Solar, fēnix 7S
fēnix 7S Solar, fēnix 7X, fēnix 7X Solar, fēnix S8, Forerunner 245, Forerunner 245 Music, Forerunner 255 / S /
Music, Forerunner 45, Forerunner 45 Plus, Forerunner 45S, Forerunner 55, Forerunner 745, Forerunner 935,
Forerunner 945, Forerunner 945 LTE, Forerunner 955 / Solar, Garmin Swim 2, Instinct, Instinct 2,
Instinct 2S, Legacy Hero -sarja, quatix 5, quatix 5 Sapphire, quatix 6, quatix 6 Titanium, quatix 6x Solar,
quatix 7 / 7X Solar, STRIKER Cast, STRIKER Cast GPS, tactix® 7, tactix® Charlie, Venu, Venu 2, Venu 2S,
Venu 2 Plus, Venu Sq, Venu Sq Music Edition, Venu Sq 2 / Music, vívoactive 3, vívoactive 3 Music,
vívoactive 4, vívoactive 4s, vívomove 3, vívomove 3S, vívomove Luxe, vivomove Sport, vívomove Style,
vívosmart 5, vívosport®.